

Fig. 1

1/5




Fig. 2

2/5




Fig. 3




Fig. 4

(a)

ONE-TOUCH KEY SETTING MENU												
KEY	1	2	3	4	5	6	7	8	9	10	11	12
No.	000	001	003	008	005	002	007	006	009	010	...	...
No.	BROADCASTING STATION NAME			CHANNEL STRUCTURE								
001	○△×			101	102	103	401	701				
002	△△ BROADCASTING DIGITAL			151	152	451	452	751				
003	DIGITAL □□			171	771							
004	DIGITAL ××			161	461	761						
005	○○ DIGITAL BROADCASTING			141	142	441	741	742	743			

ONE-TOUCH KEY SETTING PORTION

BROADCASTING STATION LIST PORTION

(b)


ONE-TOUCH KEY SETTING MENU												
KEY	1	2	3	4	5	6	7	8	9	10	11	12
No.	004	001	003	008	005	002	007	006	009	010	...	...
No.	BROADCASTING STATION NAME			CHANNEL STRUCTURE								
001	○△×			101	102	103	401	701				
002	△△ BROADCASTING DIGITAL			151	152	451	452	751				
003	DIGITAL □□			171	771							
004	DIGITAL ××			161	461	761						
005	○○ DIGITAL BROADCASTING			141	142	441	741	742	743			

ONE-TOUCH KEY SETTING PORTION

BROADCASTING STATION LIST PORTION


Fig. 5

(a)



16a

(b)



16a